

DENON®

AVR-X540BT

AV SURROUND RECEIVER

Quick Start Guide

Kurzanleitung / Guide de démarrage rapide / Guida di Avvio Rapido /
Guía de inicio rápido / Snelhandleiding / Snabbstartsguide /
Краткое руководство пользователя / Skrócona instrukcja obsługi /
Hızlı Başlangıç Kılavuzu

Read Me First....

Bitte zuerst lesen... / Lisez-moi en premier.... / Nota preliminare.... /
Lea esto primero.... / Lees mij eerst... / Läs detta först... /
Прочитайте в первую очередь... / Przeczytaj to najpierw.... /
Önce Beni Oku...

ENGLISH

DEUTSCH

FRANÇAIS

ITALIANO

ESPAÑOL

NEDERLANDS

SVENSKA

РУССКИЙ

POLSKI

TÜRKÇE

Welcome

Thank you for choosing a Denon AV receiver. This guide provides step-by-step instructions for setting up your AV receiver.

Please do not return this unit to the store – call for assistance.


If you need help... :

If you need additional help in solving problems, contact Denon customer service in your area.

www.denon.com

Before You Begin

Required for Setup

 TV	 Speaker cables	 Speakers
 HDMI cable	 Subwoofer cable	



- When connecting this unit to a device that is compatible with the Deep Color, 4K and ARC functions, use a "High Speed HDMI cable with Ethernet" that displays the HDMI logo.
- These drawings are for illustrative purposes only and may not represent the actual product(s).

What's In the Box

Quick Start Guide		FM indoor antenna	
Safety Instructions		AM loop antenna	
Cautions on Using Batteries		Sound calibration microphone	
Notes on radio		Remote control unit (RC-1216)	
Receiver		R03/AAA batteries	
Power cord			



- Using your own tripod enables settings to be automatically configured to the optimum listening environment, providing exceptionally high performance.

Setup

There are four steps to the setup process.

1 Installing batteries in the remote control unit


2 Connecting the receiver

3 Following the On-Screen Setup Assistant

4 Enjoying music using Bluetooth


1

Installing batteries in the remote control unit




2 Connecting the receiver

- 1) Place the receiver near your TV and connect the power cord





2) Connect the receiver to your TV with an HDMI cable



ARC (Audio Return Channel) :


If your TV supports ARC, your TV can send audio back to the AV receiver when you are using your TV's built-in video sources (TV tuner, Smart TV streaming services, etc...) ARC requires that you enable HDMI CEC on your TV. Please refer to your TV's Owner's Manual for instructions on how to setup HDMI CEC. Note that some TV manufacturers use other names for the HDMI CEC function.

3) Turn on the TV



TV remote control unit


4) Select the appropriate HDMI input on your TV



TV remote control unit


5) Turn on the receiver

- Press  to turn on the receiver.



6) Verify the connection


- Verify that you can see this screen on your TV.



If this screen is not displayed, please go back and retry the steps again in the recommended sequence.


3 Following the On-Screen Setup Assistant

The Setup Assistant will walk you through connecting and configuring your speakers and components to your Denon receiver. Please use the remote control and follow the on-screen instructions.




4 Enjoying music using Bluetooth


- 1 Press and hold the Bluetooth button on the remote control for at least 3 seconds to go into pairing mode.



- 2 Activate the Bluetooth settings on your mobile device.



- 3 Select "Denon AVR-X540BT" from the Bluetooth device list on your mobile device.



- 4 When a number appears on the display of this unit, check that it is the same number as that shown on the screen of the Bluetooth device and then select "Pair" for both the Bluetooth device and the unit.
- 5 Play music using any App on your device.



To reconnect a previously paired Bluetooth device, Start at step 2.

Owner's Manual

- For more information, visit www.denon.com
- Refer to the Online Manual for other functions information and operation procedure details. manuals.denon.com/AVRX540BT/EU/EN/



Online Manual



Compatible with the “Denon 500 Series Remote” App



The “Denon 500 Series Remote” App allows you to remotely control the AVR-X540BT from your mobile device when connected via Bluetooth. It is available for free in the Apple App Store, Google Play or the Amazon Appstore. Make sure you search for “DENON 500 SERIES”.





DENON®
www.denon.com

Printed in Vietnam 5411 11473 00AD
Copyright © 2017 D&M Holdings Inc. All Rights Reserved.