



Control / 控制



Rotate / 旋转:
Adjust volume / 调节音量大小

Short press / 短按:
Startup / 开机
Shutdown, timed shutdown
restart or screen off
/选择关机/定时开机/重启/关屏

Long press / 长按:
Shutdown / 关机




Source / 信号源

FN / 自定义


SSD Installation (Bottom) / SSD 硬盘安装 (底部)

* SSD: M.2 (NVMe PCIe3.0) 2280, up to 4TB / 支持规格: M.2 (NVMe PCIe3.0) 2280, 最大支持4TB




① Remove the lid / 掀开盖板

* load and unload when power off
务必在断电情况下装卸硬盘



② Unfastening / 拨开固定扣

* Unfasten by pulling up the ring
向上提起固定扣环将插针拔出




③ Install SSD / 装入硬盘

* Insert the SSD and fasten it again
装入硬盘后将插针对准插孔按紧

Device Connection / 设备连接


* For more details, please refer to the electronic manual.
详细设备连接请查看电子档说明



20230912-DMP-A8说明-V1.1(黑卡)
成品尺寸:161x161(mm)
展开尺寸:483x161 (mm)

 PMS 877U

Interface / 界面



Now playing / 现在播放

Media Control / 媒体控制

Home / 主页

Return / 返回



Function Display and Control Area/ 功能显示与控制区

* For more details, please refer to the electronic manual.
详细功能操作请查看电子档说明



User Manual
说明书



Control APP
控制 APP



Wechat Subscription
微信公众号

For USB audio driver, firmware and more,
please visit the Downloads page of www.eversolo.com
USB音频驱动、固件, 更多资源下载请访问: www.eversolo.com



Quick Start Guide
快速入门指南

折叠后背面

折叠后正面